SWITCHING IN NETWORKING

Framework Used: The Why, What, and How.

Why Learn Switching?

- 1. **Efficient Communication**: Switches control how data is forwarded in a network, ensuring efficient communication between devices.
- 2. **Scalability**: Switching is the backbone of enterprise networks, allowing them to grow and handle more devices.
- 3. **Security and Control:** Advanced switching features, i.e., VLANs and port security, enable secure and segmented networks.

What is Switching?

1. Definition: Switching is the process of forwarding data packets (frames) between devices in a network based on L2 (datalink) or L3 (network) information.

2. Types of switching:

• Layer 2 Switching : Based on MAC addresses

 Layer 3 Switching: Incorporates routing capabilities using 10 addresses.

3. Switching Modes:

- Cut Through: Forwards frames as soon as the destination MAC is read

 (low latency but no error checking)
- Store-and-Forward: Buffers and verifies the frame before forwarding
 (High latency but error-free)
- Fragment-Free: Checks the first 64 bytes for errors, then forwards by compromising between speed and reliability.

How Does Switching Work?

1. Switch MAC Address Table

- Switches learn which MAC addresses are connected to which ports by examining the source MAC address of incoming frames.
- Frames are forwarded to the destination MAC based on this table.
- Unknown destinations trigger flooding (broadcasting to all ports).

2. Frame Switching Process

- Receives a frame
- Looks up the destination MAC in the MAC address table

- Forwards it to the corresponding port.
- If the destination MAC is not found (an unknown destination), the switch floods the frame, sending it out to all ports except the one on which it was received.

TO NOTE:

- → Unicast Frame: If the Mac table has the destination MAC, the switch sends the frame to the specific port.
- → Broadcast Frame: Since the destination MAC is FF:FF:FF:FF:FF; the frame is transmitted to every port.
- → Unknown Frame: If the destination MAC is not in the table, the frame is flooded to all ports, except the incoming port.

Practical Lab: Observing the MAC Address Table

Objective:

- Learn how switches dynamically (automatically) learn and update their MAC address table.
- Connect two PCs (PCI and PC2) to a switch on ports Fa0/I and Fa0/2.
- Set up IP addresses for both PCs.


• Ping from PCI to PC2.

Topology:

- 1 Switch
- 2 PCs (PC A and PC B)

Steps:

- 1. Connect PCs to the Switch:
 - o PC A: Port Fa0/1
 - o PC B: Port Fa0/2



2. Check the Initial MAC Address Table:

```
Switch#show mac address-table

Mac Address Table

-----

Vlan Mac Address Type Ports
```

3. Generate Traffic:

```
C:\>ping 10.1.1.5

Pinging 10.1.1.5 with 32 bytes of data:

Reply from 10.1.1.5: bytes=32 time=15ms TTL=128
Reply from 10.1.1.5: bytes=32 time<1ms TTL=128
Reply from 10.1.1.5: bytes=32 time<1ms TTL=128
Reply from 10.1.1.5: bytes=32 time<1ms TTL=128

Ping statistics for 10.1.1.5:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 15ms, Average = 3ms</pre>
```

TO NOTE:

Test for communication from the above topology;

- The switch learns the PC's MAC when the ping starts.
- If the laptop's MAC isn't already in the table, the switch floods the packet.

• The laptop responds, and its MAC address is added to the MAC table.

4. Verify the MAC Address Table:

| Switch#show mac address-table Mac Address Table | | | |
|--|----------------------------------|--------------------|----------------|
| Vlan | Mac Address | Туре | Ports |
| 1 | 0030.a387.949d 0090.2b75.8b57 | DYNAMIC DYNAMIC | Fa0/2 Fa0/1 |

Note:

- → Vlan: The VLAN ID associated with the MAC address.
- → MAC Address: The unique identifier of the device.
- → Type: Indicates how the MAC address was learned (e.g., dynamic means it was automatically learned by the switch.)
- → Ports: The port the MAC address is connected to.

Troubleshooting a possible network issue during switching, especially on the MAC Address Table.

Issue: A computer cannot communicate with the network;

• If the computer's MAC address isn't listed, it may not be sending traffic to the switch.

WHY??

- Cable issue
- NIC Problem

NB o You should also check on the ports and ensure they are up and receiving traffic.